

# Work Order ID 79461

**\*79461\***

Page 1

January-26-12 9:31:00 AM

Item ID: D206-642-114

Accept

**\*N900040100\***

Setup Start **\*NS1\***

Revision ID:

Stop **\*NS2\***

Item Name: Skidtube RH

Start Date: 26/01/2012 Start Qty: 1.00

**\*1\***

Cust Item ID:

Required Date: 15/03/2012 Req'd Qty: 1.00

**\*1\***

Customer:

Reference:

Approvals: Process Plan: MLJ

Date: 12/01/26 Tooling:

Date:

Run Start **\*NR1\***

QC:

Date:

SPC (Y/N):

Date:

Stop **\*NR2\***

Sequence ID/ Work Center ID	Operation Description	Set Up/ Run Hours	Tool ID	Tool #	Plan Code	Accept Qty	Reject Qty	Reject Number	Insp. Stamp
--------------------------------	--------------------------	----------------------	---------	--------	--------------	---------------	---------------	------------------	----------------

Draw Nbr

Revision Nbr

IIN-D206-642

O

100

0.00

**\*100\***

DOCUMENT CONTROL

W 12 03 19

MLJ 12/02/23

DC

Memo

0.00

Document Control

Photocopy bluefile & type labels per PPP206-642-114 CHG002  
K10112 CHG003

110

Pick Kit

0.00

**\*110\***

12/3/19 SP

Packaging

Memo

0.00

Packaging

120

QC4- 100% Inspect kits for completeness

0.00

**\*120\***

W 12 03 19 U

QC

Memo

0.00

Quality Control

W/O:		WORK ORDER CHANGES					
DATE	STEP	PROCEDURE CHANGE	By	Date	Qty	Approval Chief Eng / Prod Mgr	Approval QC Inspector

Part No: \_\_\_\_\_ PAR #: \_\_\_\_\_ Fault Category: \_\_\_\_\_ NCR: Yes No DQA: \_\_\_\_\_ Date: \_\_\_\_\_

Resolution: \_\_\_\_\_ Disposition: \_\_\_\_\_ QA: N/C Closed: \_\_\_\_\_ Date: \_\_\_\_\_

NCR:		WORK ORDER NON-CONFORMANCE (NCR)						
DATE	STEP	Description of NC Section A	Corrective Action Section B			Verification Section C	Approval Chief Eng	Approval QC Inspector
			Initial Chief Eng	Action Description Chief Eng	Sign & Date			

**NOTE:** Date & initial all entries

**Work Order ID 79461****\*79461\***

Page 2

January-26-12 9:31:00 AM

Item ID: D206-642-114

Accept

**\*N900040100\***Setup Start **\*NS1\***

Revision ID:

Stop **\*NS2\***

Item Name: Skidtube RH

Start Date: 26/01/2012 Start Qty: 1.00

**\*1\***

Cust Item ID:

Required Date: 15/03/2012 Req'd Qty: 1.00

**\*1\***

Customer:

Reference:

Approvals:

Process Plan: \_\_\_\_\_

Date: \_\_\_\_\_

Tooling: \_\_\_\_\_

Date: \_\_\_\_\_

Run Start **\*NR1\***

QC: \_\_\_\_\_

Date: \_\_\_\_\_

SPC (Y/N): \_\_\_\_\_

Date: \_\_\_\_\_

Stop **\*NR2\***

Sequence ID/ Work Center ID	Operation Description	Set Up/ Run Hours	Tool ID	Tool #	Plan Code	Accept Qty	Reject Qty	Reject Number	Insp. Stamp
130		0.00							
<b>*130*</b>	Packaging								
Packaging	Memo	0.00							
Packaging	Identify and pack for shipping as per PPD206-642-114 K10112 Location: _____ PPP Rev: _____								
140	QC21- Final Inspection - Work Order Release	0.00							
<b>*140*</b>									
QC	Memo	0.00							
Quality Control									

MLJ 12/03/19

MLJ  
12.03-19

W/O:		WORK ORDER CHANGES					
DATE	STEP	PROCEDURE CHANGE	By	Date	Qty	Approval Chief Eng / Prod Mgr	Approval QC Inspector

Part No: \_\_\_\_\_ PAR #: \_\_\_\_\_ Fault Category: \_\_\_\_\_ NCR: Yes No DQA: \_\_\_\_\_ Date: \_\_\_\_\_

Resolution: \_\_\_\_\_ Disposition: \_\_\_\_\_ QA: N/C Closed: \_\_\_\_\_ Date: \_\_\_\_\_

NCR:		WORK ORDER NON-CONFORMANCE (NCR)						
DATE	STEP	Description of NC Section A	Corrective Action Section B			Verification Section C	Approval Chief Eng	Approval QC Inspector
			Initial Chief Eng	Action Description Chief Eng	Sign & Date			

**NOTE:** Date & initial all entries

# Picklist Print

January-26-12 9:31:04 AM

Page 1

Work Order ID: 79461

**\*79461\***

Parent Item: D206-642-114

**\*D206-642-114\***

Parent Item Name: Skidtube RH

Start Date: 26/01/2012

Required Date: 15/03/2012

Start Qty: 1.00

Required Qty: 1.00

Comments: IPP REV:A 10.12.08 PER REV:N DD VERF:EC IPP REV:B  
11.09.23 ADDED K10112 DD VERF:EC IPP REV:C  
REDESIGN PER ENG ERROR 11-11-17 JLM VERIFIED BY:DD

Component Item ID/ Item Name	Replacement Item ID	Mfg/ Purch	Bin Item	Primary Location	Last Location	Route Seq ID	Unit of Measure	Qty on Hand	Qty per Kit	Total Qty	Qty Issued	Date Issued	Status
D206-642-151		Manufactured	No			110	Each	0.0000	1	1			
<b>*D206-642-151*</b>									<b>**</b>				
Replacement Skidtube													
K10112		Manufactured	No			110	Each	0.0000	1	1			
<b>*K10112*</b>									<b>**</b>				
Saddle, Skidtube 206													

K10112

-1

79576

<b>DART</b> Dart Aerospace Ltd. 1270 ABERDEEN ST. HAWKESBURY ONT CANADA K6A 1K7				TC APPROVAL # 09-89 TEL: 1-613-632-5200	
PN	D206-642-113	CHG	CHG002		
DESC	Skidtube Assembly	SIC	SH98-4		
LOT	B79432	SIC	SA00475SE		
MODEL	Bell 206A/B	SIC			
MADE IN CANADA					

pull from  
stock  
~~Discardable~~  
Remove  
K10112 # 79576

W/O:		WORK ORDER CHANGES					
DATE	STEP	PROCEDURE CHANGE	By	Date	Qty	Approval Chief Eng / Prod Mgr	Approval QC Inspector

Part No: \_\_\_\_\_ PAR #: \_\_\_\_\_ Fault Category: \_\_\_\_\_ NCR: Yes No DQA: \_\_\_\_\_ Date: \_\_\_\_\_

Resolution: \_\_\_\_\_ Disposition: \_\_\_\_\_ QA: N/C Closed: \_\_\_\_\_ Date: \_\_\_\_\_

NCR:		WORK ORDER NON-CONFORMANCE (NCR)						
DATE	STEP	Description of NC Section A	Corrective Action Section B			Verification Section C	Approval Chief Eng	Approval QC Inspector
			Initial Chief Eng	Action Description Chief Eng	Sign & Date			

**NOTE:** Date & initial all entries